YachtSafe GPS alarm

do your own installation in 5-10 minutes



Installation of the alarm unit

Open the box for the alarm unit and the installation kit

- 1. Open the fuse holder and push in the fuse all the way in then close the fuse holder again until you hear a click.
- 2. Scale the plastic, about 1 cm, at the ends of the fuse holder cables as well as the unit's black and red cables.
- 3. Plug the unit's red cable into one end of the connector and at the other end of the connector, push in one of the fuse holder's cabels. Pinch the cable pliers in the middle of the connector and gently feel that the cables are stuck.
- 4. Similarly fasten the ring pins on the second cable of the fuse holder as well as on the black cable of the unit and feel carefully after the cables are attached.
- 5. Take the two ring pins and screw in your battery (12V / 24V): red cable with fuse on the plus terminal and Black cable on the negative terminal.

You need:

A pliers, to scale plastic from cables and pinch the connectors and round pin

Installation kit:

1 pcs Fuse 3A

1 pcs Fuse Holder Black

2 pcs Round pin 6.4mm

2 pcs Connectors (1 pcs extra)

Attachments or adjustments to this Manual can be found at yachtsafe.se under the Manuals tab.

